

Quick Start Guide

BirdBike

V-FRAME

BirdBike Assembly Video

Scan to watch the assembly video and download your Quick Start Guide in multiple languages.



Need help?

Please reach out to us directly with any questions,

Visit support.bird.co

Bike. Please do not contact the retailer.

Attach the handlebars Attaching the handlebar to the handlebar stem on top of the fork

1 Preparation for assembly

· Expect ~30 minute assembly time

ЛΛ

Wheel Reflectors and fasteners (x2)

Unpack all components from the product

· Clear a work space

· Don't over tighten screws

package including the Toolkit

Tools:

Parts:

 Place the handlebar over the handlebar stem and insert the hex bolt (from step 2) through the handlebar.

Using the 5mm end of the Y-wrench, gently tighten the hex bolt so that there's no play between the fork and frame.

Install the seat

reveal the seat clamp screw.

Do not extend the seat post

insertion line indicated on the

farther than the minimum

to the frame.

seat post.

2 Use the 5mm end of the Y-wrench to

Remove the soft rubber cap located on

the frame just below the seat column to

loosen the seat clamp screw. Adjust the

seat post to the preferred height. Once

positioned, tighten the seat clamp screw

until secure and return the rubber cap in

And adjust the seat height







Tool


required

Y-wrench

Attach the pedals

Screw the left pedal marked "L" counter-clockwise by hand (since it is reverse threaded).

Tighten both pedals with the 15mm



14 Bird app

Download the latest version of the Bird app and





Press the power button on the left handlebar to

turn on your Bird Bike.

Find the QR code for your Bird Bike located inside the toolkit or on front cover of the contact your retailer.

This is where you can view the details of your Bird Bike and use the available features.

Bike Screen through "Private Birds" in the menu.

We're here for you.

concerns or if you need help assembling the Bird

Email shopemea@bird.co

3 Remove the dash display Removing the screw from under LED display

Gently pull the LED display out from its enclosure within the handlebar. Be careful not to damage any cables.



Remove the screw from under the LED display using the 2.5mm Allen key. Set aside the screw for use during installation in **step 11**.



Tool

required


Wrench

Parts

required

Tool

required



7 Install the front wheel Attach the front wheel to the fork

- Remove the black fork protector from the bottom of the fork and discard.
- Insert the front wheel axle inside of the fork slots. Ensure the brake rotor is aligned to fit inside the front disc brake.
- Install washers (serrated side in) and cap nuts onto the outsides of the fork. Tighten them using the 15mm wrench until secure.
- The correct tire pressure is 3.5-5.6 bar.



Reinstall the led display Reinstall the display

- Place the display back into the handlebar enclosure. Be careful not to pinch the cables.
- 2 Use the 2.5mm Allen key, reinstall the screw previously removed in step 3 from under the display, so that the display fits flush inside of the handlebar enclosure.
- Connect the end of the power cable coming from the bottom of the display to the power cable coming out of the bottom of the frame. Carefully align the arrows on the cables.




Tool

required

2.5mm

Allen key



Aligning the front fork (before mounting the handlebars)


4 Install the handlebars

- Align the fork with the frame so that it is facing forward, the front brake assembly should be on the same side as the kickstand. (rider's left side)
- Make sure the cables are clear and do not restrict the range of motion needed for



8 Attach the front fender Attach the front fender to the fork

With the 4mm end of the Y-wrench, remove the two screws attached to the back of the fork.



A Re-insert the two screws through the holes at the end of the fender-support bracket to secure them on to the fork.

Use the 4mm end of the Y-wrench to

remove the screw that's on

the top of the backside of the fork. ▲ Re-insert the screw through the fender

mount bracket on top of the fender and secure tightly to the back of the fork.





12 Charge battery

Connect the charger

Tip: Make sure fender is parallel to the wheel so it doesn't make contact as the wheel rotates.

> Use the included power supply and connect it to the charging port on the battery (below the +/- rubber flap).

Finish Charging When fully charged, a green light on the power supply indicates the charge is complete. Battery can be charged on the

4-6 hours to fully charge your bike.

Bike or removed for charging. Please allow



13 Install reflectors

Rear reflector - red

Wrap the bracket for the rear reflector around the seat post. Secure with a flathead screwdriver. Position the reflector facing rearward.

Front reflector - white Wrap the bracket for the front reflector around the handlebar near the stem.

Wheel reflectors

around any wheel spoke. Secure with a flathead screwdriver.
















Wrap the bracket for the wheel reflector





2 Prep the handlebar stem Remove the hex bolt, cap, and cardboard

Tool

required

Y-wrench

Set aside

Hex bolt

Remove the hex bolt screw from the

Set aside the hex bolt for use during


black cap held in by the hex bolt.


cardboard tube on the handlebar stem.

Discard both the cardboard tube and the

tube from handlebar stem

installation in step 5.








Screw the right pedal marked "R" clockwise.




Tool

required









After pairing, the My Bird Bike screen will appear.

After closing the Bird app, access the My Bird